

Travel hair dryer

User's manual

EN



SENCOR®

SHD 6400B / SHD 6400V

Prior to using this device, please read the user's manual thoroughly, even in cases, when one has already familiarised themselves with previous use of similar types of devices. Use the device only in such a way as described in this user's manual. Store the user's manual in a safe place where it can be easily retrieved in case of future need.

We recommend saving the original shipping cardboard box, packaging material, receipt and warranty card for the duration of warranty. In case of transport wrap the device in the original box from the manufacturer.

EN-1

CONTENTS

IMPORTANT SAFETY NOTICE	3
DESCRIPTION OF THE DEVICE	4
INSTRUCTIONS FOR USE.....	4
MAINTENANCE AND CLEANING.....	5
TECHNICAL DETAILS.....	6
SUPPLIED PARTS:	6
DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT.....	6
INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS	6

Travel hair dryer

SHD 6400B / SHD 6400V

EN

IMPORTANT SAFETY NOTICE

- Carefully unpack the product and take care not to throw away any part of the packaging before you find all the parts of the product.
- This product must not be used by persons (including children) with physical or mental impairments or by inexperienced persons, unless properly trained or schooled in the safe use of the product, or unless they have been properly supervised by a qualified person who will be responsible for their safety.
- Use extra care if the product is used near children. Always keep the product out of the reach of children. Children must be supervised to ensure that they do not play with the product.
- Before plugging this device in, make sure the voltage stated on the label of the device corresponds to the voltage of your wall socket.
- Never use the dryer in the near vicinity of a bath, shower or swimming pool.
- Never use accessories, which have not been supplied with this device or which are not designed for this device.
- Make sure that the electric cable and plug cannot get in contact with water or dampness.
- Do not spray the device with water, nor with any other liquid. Do not submerge this device and any of its components in water, or any liquids.
- The device is designed for household use. Do not use the dryer in industrial environment, or outdoors.
- Do not use sprays in the vicinity of the device.
- If you will not be using the device, disconnect it from the electrical grid. Before cleaning or moving proceed in the same manner.
- Do not place the device on or near an electrical or gas stove. Do not place the device within near heat producing devices such as fireplaces etc.
- Do not use the device if it has a damaged electric cable/electric cable plug.
- In no case should you attempt to repair the unit yourself, do not make any amendments to it - danger of electric shock! Entrust all repairs and adjustments to a specialised company/service. Tampering with the device during the guarantee period may invalidate the guarantee.
- In case the electric cable is damaged, have it replaced by an expert service. Do not use the device if it has a damaged power cord/plug.
- Do not place the electric cable of the device near hot surfaces, or over sharp objects.
- Do not place heavy objects on the cable, position the cable so that it is not stepped on, or tripped over. Make sure the power cable does not hang over the edge of a table, or that it does not touch a hot surface.
- Do not disconnect the device from the power point by pulling the electric cable - it may damage the electric cable/power point. Disconnect the cable from the power point by gently pulling the plug of the electric cable.
- Do not use the device for other purposes than it is intended for.
- Ensure that when turning on the device, that the grill air inflow or outflow grill is not covered.
- Ensure that no hair or threads remain in any of the openings of the dryer.
- In case you use the device in the bathroom, unplug it from the socket after use by removing the plug from the socket, as the presence of water poses danger, even when the hair dryer is turned off.
- To ensure additional safety, it is recommended to install an Residual Current Device (RCD) into the electric circuit to the bathroom with a maximum current rating of 30 mA. Ask the electrician for advice.
- The manufacturer is not responsible for damages caused by incorrect use of this device or its accessories. Such damages include food spoilage, injuries, burns, scalding, fire, etc.



Do not use this appliance near baths, showers, washbasins or other containers containing water.

Travel hair dryer

SHD 6400B / SHD 6400V

DESCRIPTION OF THE DEVICE



- ① Air concentrator
- ② Cold air button
- ③ Switch:
0 = turned off
1 = gentle drying
2 = fast drying
- ④ Air inflow opening grill
- ⑤ Protective rubber side guard
- ⑥ Joint
- ⑦ Foldable handle
- ⑧ Hanging loop

INSTRUCTIONS FOR USE

- 1) Insert the plug into the power socket.
- 2) On the handle of the dryer select I. or II. power level and at a distance of approximately 10 cm from the head begin drying.



Tip:

To achieve the best results wash your hair with shampoo before using the dryer, then dry your hair using a towel to reduce excessive moisture and then comb your hair. We recommend the use of a conditioner or hair lotion, which simplifies the combing and then drying of your hair.

Power levels

I. power level:

- gentle air flow
- low temperature

II. power level:

- powerful air flow
- high temperature

Travel hair dryer

SHD 6400B / SHD 6400V

EN

Cold air button

The cold air button can be used in combination with any power level and is ideal for fixing a hairstyle after drying with hot air.



Note:

It is necessary to hold the cold air button for the whole time; after it is released, hot air will flow again.

Air concentrator

If when drying your hair you need to style it (i.e. concentrate the air flow on a given area), attach the concentrator on to the out flow opening of the dryer.

Foldable handle

This hair dryer is equipped with a foldable handle making it possible to close it into a shape, which takes up very little space during your travels (see picture).



MAINTENANCE AND CLEANING



Note:

Before cleaning, always disconnect this device from the power source.

To clean the outer parts of the product, use a soft cloth dipped in lukewarm water. Do not use aggressive cleaning products and solvents as this could damage the surface of the product.

Travel hair dryer

SHD 6400B / SHD 6400V

TECHNICAL DETAILS

Voltage	230 V AC
Nominal frequency	50 Hz
Power input	850 W
Safety class (with regard to electric shock protection)	II
Noise level.....	72 dB(A)

The declared noise emission level for this appliance is 72 dB(A), which represents level A of the acoustic power relative to the reference acoustic power of 1 pW.

SUPPLIED PARTS

- 1) Hair dryer
- 2) Air concentrator
- 3) User's manual
- 4) Warranty card

The manufacturer reserves the right to alter the text and technical parameters.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines.

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.

Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.



This product meets all the basic EU regulation requirements that relate to it.

Changes to the text, design and technical specifications may occur without prior notice and we reserve the right to make these changes.